



Frequency range A

XS Wireless In-Ear Monitoring System



Ergänzende Informationen
 Supplementary Information
 Informations supplémentaires
 Informazioni supplementari
 Información adicional
 Informações suplementares
 Aanvullende informatie
 Dodatkowe informacje
 Yderligere oplysninger

Ytterligere informasjon
 Turvallisuusohjeita
 Επιπλέον πληροφορίες
 Kullanım Kılavuzuna Ek
 Дополнение к инструкции
 使用说明书补充
 取扱説明書の増補
 사용 설명서에 대한 보충사항
 معلومات إضافية

Sennheiser electronic GmbH & Co. KG

Am Labor 1, 30900 Wedemark, Germany
www.sennheiser.com

Publ. 01/22, 587451/A02

SENNHEISER

DE

Für die Übertragung steht Ihnen folgender Frequenzbereich zur Verfügung:

Frequenzbereich	Bandbreite	Anzahl Frequenzen
476 - 500 MHz	24 MHz	max. 961

Die Sender und Empfänger verfügen über jeweils 8 Kanalbänke, auf denen werksseitig Frequenz-Presets voreingestellt sind. Innerhalb einer Kanalbank sind die Frequenz-Presets untereinander intermodulationsfrei. Sie sind nicht veränderbar.

In der Kanalbank **U** können Sie in 25-kHz-Schritten Frequenzen frei einstellen und abspeichern. Diese sind unter Umständen nicht intermodulationsfrei.

Die Frequenz-Presets in den Kanalbänken **1 bis 8** sind in der Tabelle auf der folgenden Seite dargestellt.

Rahmenbedingungen und Einschränkungen für die Nutzung von Frequenzen

In Ihrem Land gelten möglicherweise gesonderte Rahmenbedingungen und Einschränkungen für die Nutzung von Frequenzen.

Informieren Sie sich vor der Inbetriebnahme des Produktes unter folgender Adresse:

www.sennheiser.com/frequency-information

EN

Transmitters and receivers are available in the following frequency range:

Frequency range	Bandwidth	Number of frequencies
476 - 500 MHz	24 MHz	max. 961

Transmitters and receivers have 8 frequency banks respectively. Each of the channels in the frequency banks has been factory-preset to a frequency. These frequency presets within one frequency bank are intermodulation-free. They cannot be changed.

The frequency bank **U** allows the user to store individual frequencies which are freely selectable in 25-kHz steps. It might be that these frequencies are not intermodulation free.

The table printed on the following page lists the frequency presets in the frequency banks **1 to 8**.

Conditions and restrictions for using frequencies

There may be special conditions and restrictions for using frequencies in your country.

Before putting the product into operation, find the information for your country at the following address:

www.sennheiser.com/frequency-information

Frequenzbereich A / Frequency range A: 476 - 500 MHz

US TV channel	CH 15 (476 - 482)	CH 16 (482 - 488)	CH 17 (488 - 494)	CH 18 (494-500)
EBU TV channel	CH 21 (470 - 478)	CH 22 (478 - 486)	CH 23 (486 - 494)	CH 24 (494-502)

Channel	Bank 1	Bank 2	Bank 3	Bank 4	Bank 5	Bank 6	Bank 7	Bank 8
1	476.200	482.200	488.200	494.200	478.200	486.200	494.200	476.200
2	476.800	482.800	488.800	494.800	478.800	486.800	494.800	481.000
3	477.700	483.700	489.700	495.700	479.700	487.700	495.700	484.300
4	478.900	484.900	490.900	496.900	480.900	488.900	496.900	489.400
5	480.700	487.300	492.700	498.700	482.700	490.700	498.700	493.000
6	483.100	476.200	476.200	476.200	485.100	493.100	476.200	495.400
7	486.700	478.000	478.600	478.600	488.400	476.900	478.600	497.200
8	491.800	492.700	481.900	481.900	493.200	480.200	481.900	498.400
9	495.100	495.700	496.300	486.100	496.800	497.900	486.100	499.300
10	499.900	499.000	477.550	476.950	476.250	476.200	476.950	499.900
11	482.050	481.150	482.650	480.550	492.450	478.800	480.550	476.950
12	497.950	494.950	498.550	488.950	499.050	494.100	488.950	494.050