


Menu Display


The Menu Display combines a Dell™ computer with a touchscreen into a single unit that can be installed onto a standard VESA-100 mount. The Menu Display connects to the switcher over ethernet to provide the menu system interface to the setup and operation of your Acuity® switcher.

Ports



Power and Cabling


The power cord adapter is needed to plug the provided line cord into the power supply for the PC of the Menu Display.



Note: It is recommended that you always connect the AC Power Adapter to the device before connecting to Mains Power.

Mounting

The Menu Display can be installed onto an arm supporting a standard VESA-100 mount.



Mounting Specifications:

- Mounting Interface: VESA MIS-D, 100, C
- Unit Weight: ~16lbs (7kg)

Dell™ Ownership Transfer

The ownership and warranty of the Dell™ PC that comes with the Menu Display needs to be transferred from Ross® to your organization.

Navigate to <http://www.dell.com> and click **Support** > **Warranty** > **Transfer of Ownership**. Follow the instructions on the web page using the following information:

- **Service Tag Number:** The website provides information on obtaining this number.
- **Previous Owner First Name:** Ross Video
- **Previous Owner Last Name:** Ross Video
- **Previous Owner Company:** Ross Video
- **Previous Owner Zip Code:** K0E 1K0