

LR-3200

QUICK START GUIDE



Congratulations

This Quick Start Guide will explain the basics of using your receiver. Experience how Listen Technologies brings power and clarity to the sounds that enrich our lives.

Button Basics

Power:

To turn on the receiver press and hold the power button for 1 second, the top LED will dimly illuminate. To turn off the receiver, press and hold for 3 seconds, the LED will extinguish.

Volume:

To adjust the volume momentarily press the up or down button until the volume is comfortable.

Channel Select:

Channel E is the default channel. Channels A, E, & H are available in basic mode.

To change the default channel press and hold both volume buttons at the same time for 5 seconds. The front program LED will begin to flash red. Use the volume up or down button to scroll through the available channels. Current channel will be heard in the ear speaker. Momentarily press the power button to lock the receiver on the selected channel.

Setup Instructions

Remove the clear plastic pull tab and fully charge the battery. When

fully charged the top LED is solid, indicating 100% charged. Connect the Earphone/Neck Loop Lanyard and ear speaker or headphones to the output jacks.

Charging:

When the battery is low the top LED will begin to flash slowly. To charge, place the unit in the charging tray/case or connect the Micro USB to any standard USB port.

We Care

Hearing Protection:

This product is designed to amplify audio to a high volume level which could potentially cause hearing damage if used improperly. To

protect your hearing, make sure the volume is turned down before putting on the ear speaker or headphones, the adjust the volume to your preference. Children should be supervised when using this product.

Medical Device Safety

Before using this product with an implantable or other device consult with your physician or manufacturer of the device. Always make sure you are using this product in accordance with the safety guidelines established by your physician or the manufacturer.

Recycling

Please help us protect the

environment by properly disposing of the batteries. Take batteries or equipment to any electronic recycling collection point or return them to the factory.

To purchase additional accessories visit www.listentech.com/shop

For further details regarding use, adjustment, or programming of your Listen products visit us at www.listentech.com/support/manuals

or contact us at

+1.801.233.8992 or 1.800.330.0891



©2019 Listen Technologies Corporation
All Rights Reserved 20181126